






Kit 1423

AUDI A6, 4-dr Sedan, 04–




750









1




2



+




3





AUDI A6, 4-dr Sedan, 04–

X
36





AUDI A6, 4-dr Sedan, 04–

Y
36



AUDI A6, 4-dr Sedan, 04–

X inch	X mm
39 3/4"	1011 mm





AUDI A6, 4-dr Sedan, 04–


Y inch	Y mm
39 3/4"	1011 mm

4








AUDI A6, 4-dr Sedan, 04–




5



	X mm	Y mm	X inch	Y inch
AUDI A6, 4-dr Sedan, 04–	215 mm	790 mm	8 1/2"	31 1/8"







6










GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokrétla багаžníka dokręcaj dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγείτε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ขันในแบบสลับ



7





THULE
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA